



SHOCKER MINI CUSHION HITCH INSTALLATION INSTRUCTIONS

INSTALLTION

-**IMPORTANT:** Before installing the Shocker Mini, double check the orientation of the bushings as they are rated for different towing weights (see Figure 1 & 2).

-Install the unit into the receiver tube on the tow vehicle, then install 5/8" hitch pin.

-Install ball mount that is provided with the unit using the provided ball mount pins and secure with clips. Note: You can remove the ball portion of the mount and install it "backwards" to make the mount raised or drop (see Figure 1 & 2). This mount can provide you with 2" of drop OR 2" of rise)

-Once hitch is installed and secure, hook up trailer using proper height adjustments and secure with trailer coupler and pin.



FIGURE 1: BLACK bushings facing "upward" the weight is on the **GREEN** bushing - 2,000 lb GTW & 200 lbs TW



FIGURE 2: **GREEN** bushings facing "upward" the weight is on the **BLACK** bushing - 3,500 lb GTW & 350 lbs TW

SAFETY NOTICE

-The Shocker Mini is a light-duty unit, it is imperative that any weight capacity ratings are not exceeded on the receiver that is mounted on your tow vehicle, or the Shocker Mini itself. Any modification to the hitch voids warranty and is done so at your own risk. Manufactured by Shocker Hitch, LLC in Jamestown, ND USA.

QR CODES

-Check out the QR codes for digital copies of the installation guides and to register your Shocker Mini for any warranty needs - visit www.shockerhitch.com/warranty for more info.



INSTALLATION GUIDES



WARRANTY REGISTRATION

THANK YOU FOR CHOOSING SHOCKER HITCH

Shocker Hitch: Safer Smoother Towing - 2801 3RD AVE SW, JAMESTOWN ND, 58401 - (701)-707-2666

Email: orders@shockerhitch.com Website: www.shockerhitch.com Videos on [Shocker Hitch YouTube Channel](#)