

## **SHOCKERHITCH SETUP INSTRUCTIONS GN SURGE W/CRANK STYLE STEM**

Installation:

1. Remove 3/8" bolt and handle assembly from top of trailer. (See pic #1)
2. Carefully support coupler stem while loosening set screws, allow coupler stem to slide out of trailer. (See pic # 2)
3. Remove bearing and 3/8" thick washer from original stem and install on new Shockerhitch stem. Be careful - some bearing assemblies are two piece and will easily separate allowing ball bearings to scatter. (See pic # 3)

*Note: A generous amount of grease should be applied to and around threaded shaft on new stem.*

4. Carefully slide new Shockerhitch stem up into trailer until fully engaged and new crank stem is exposed at top of trailer, tighten set screws to support new stem. Install one 3/8" thick washer on exposed crank stem. Ram brand couplers already have one, the Bulldog brand couplers will require the addition of a 3/8" thick washer which is supplied with the Shockerhitch. (See pic #4)
5. Reinstall the crank handle with the 3/8" bolt. You are now ready to hook up and adjust the coupler for a level trailer.



STEP #1



STEP #2



STEP #3



STEP #4