



COMBINATION PINTLE / BALL MOUNT PLATE INSTRUCTIONS

Thank you for choosing a SHOCKERHITCH

Designed for use with Shocker Receiver Air, HD, Impact & XRC cushion hitch and XR ball mount models

Mounting Plate and Pintle can be inverted for more drop or rise :

Drop Range for Air Hitch is 2-1/2" Rise to 6-1/2" Drop

Drop Range for Cushion & Solid Hitches 6" Rise to 6" Drop



PINTLE/BALL & MOUNT - UP / HIGHER

(PART# SH-331-336)

PINTLE/BALL & MOUNT - DOWN / LOWER

To invert pintle/ball, using 3/4" wrench remove four toplock nuts from assembly and invert mounting base in high or low position and reinstall nuts, torque each nut to 105 ft/lbs dry. Retorque of nuts after initial use is recommended.



MOUNTING BRACKET
(Part# SH-331)



PINTLE/BALL COMBO
(Part# SH-336-2 -or- SH-336-25)
Available with 2" or 2 5/16" ball



BOLT PATTERN
1.75" x 3.375" center to center

16,000 lbs Towing Capacity & 1,600 lbs Tongue Weight, Components may be purchased separately

SHOCKERHITCH PO BOX 162, 420 CTY RD 34, ARTHUR, ND 58006 (701) 707-2666
email: service@shockerhitch.com website: www.shockerhitch.com